

# Vacuum Air Sampling Box

## Features

- Three easy-to-operate buttons
- Fills bag without sample passing through pump
- Automatic-stop function to prevent overfill
- Collects over 100 samples with a full battery charge
- Purge function to flush bag
- Accommodates 0.5L – 2L sampling bags
- Clear-view lid
- Storage room for accessories



## Operating Instruction

1. Press the power switch to turn on the power.
2. Open the clear-view lid.
3. Place a bag inside the sampling box and attach its eyelet to the fixing pole.
4. Connect the flexible tubing inside the box to the stem of the valve of the bag.
5. Open the valve and close the sampling box.
6. Press the “SAMPLE” button on the control panel to start sampling.
7. Sampling stops automatically when the bag is full.
8. Open the lid in 6–8 seconds, close the valve of the bag, and remove the bag from the box.
9. If a bag needs to be flushed, press the “PURGE” button. When the bag is empty, press the “STOP” button.

